

Start with:

- the outside of the stocking, already sewn together with the back and turned right side out. (the front of my stocking is quilted with batting, the back has no batting)
- the lining of the stocking sewn together (leave a 3" hole in the side for turning!) right sides in.
- fabric for the cuff
- a sewn tab of fabric for hanging tab



To figure out how wide to cut your cuff fabric....measure the width of the top of your stocking, double that number and add .5 inch for the seam allowance. For the length of the cuff I cut my fabric 9"...to give me a 4.25" finished folded cuff. So this piece was 9" x 16.5"



Sew together the 9" ends of the cuff piece, use a 1/4" seam allowance.



Turn the cuff right side out so its folded at the bottom and raw edges are at the top. It should make a tube you can stick the stocking in.



Stick the cuff on and around the top of the stocking, match the raw edges and pin. You can pin the tab onto the side now also.



Stick the whole thing into the lining. The stocking and lining should be right sides together.



Pin all of the raw edges together at the top (lining, 2 cuff edges, and stocking edges).



Sew all the way around the top. Make sure you catch all the layers (lining, cuff edges, stocking).



Turn the whole thing right side out using the hole left in the side of the lining.



Finish turning it inside out and sew up the hole in the side of the lining. Stuff the lining inside the stocking and fold the cuff down. Press the edges as needed.



When you're done you'll have a nicely lined cuff and stocking with no raw seams showing.

